

homeFloww Set Product information

How it works

The homeFloww set has been specially developed to help protect and maintain the natural energy of people and pets in homes affected by radiation.

The Floww products in the homeFloww set were developed in accordance with the principle of resonance. Among other things they consist of circuits of electronic components that respond to radiation emitted by one or several radiation sources, such as a GSM or UMTS mast. The Floww products resonate with the radiation as it were. In doing so they create a subtle but distinct field that is 'fed' by the radiation source(s). This field, which we call a Floww Field, serves to offset possibly harmful radiation.

Floww Field

The flowing waves of the Floww Field created by the homeFloww set neutralise the often angular or blocked radiation and in doing so they help to promote and maintain a sense of ease and vitality in the body. Your home then becomes a place where you really do feel at home.

Range


In principle the homeFloww set has a range of 1,000 m³. The balanced interaction of the different parts of the set creates a Floww Field in every room in the house. The range may be reduced if surrounding radiation fields are extremely strong.



As far as possible Floww products are produced, packaged and transported with environment and people friendly materials.

Patent pending



homeFloww Set





Contents of the set

1. **bioFloww:**

a wooden pyramid with a 56 cm stainless steel antenna with (yellow) brass top. This product deals with high frequency airborne radiation, such as the radiation emitted by UMTS towers, high-voltage cables, and wireless networks in home (cordless telephones and WiFi systems).

2. **geoFloww:**

a wooden pyramid with a 66 cm stainless steel antenna with a red copper top. This product deals mainly with geopathic radiation that rises up through the earth.

3. **heatingFloww:**

a ± 10 cm stainless steel antenna with stainless steel attachment points. This product deals with low frequency radiation and uses the central heating system in the home to help create a Floww Field throughout the home through its interference with the other homeFloww products.

4. **electroFloww:**

a ± 15 cm stainless steel antenna with red copper attachment points. This product deals with low frequency radiation and uses the electrical system in the home to help create a Floww Field throughout the home through its interference with the other homeFloww products.


5. **aquaFloww:** a ± 20 cm stainless steel antenna with (yellow) brass attachment points. This product deals with low frequency radiation and uses the water supply system to help create a Floww Field throughout the home through its interference with the other homeFloww products.

6. **cable ties:**

8 cable ties: 6 cable ties to attach the heatingFloww, the electroFloww and the aquaFloww to the central heating, electrical and water supply systems, plus 2 additional cable ties.

Disclaimer

Floww products are not medical devices. If you have a physical ailment, it is always best to seek medical advice. Floww products should only be used as indicated in the accompanying information.



homeFloww Set instructions for use

Installing the homeFloww Set

1. Place the bioFloww on the floor in the *highest* room in your home. (See diagram 1a.)
2. Place the geoFloww on the floor in the *lowest* room in your home. (See diagram 1a.)
3. Please note: seen from above, the geoFloww and bioFloww need to be diagonally opposite one another. (See diagram 1b.)
4. If you live in an apartment, the geoFloww and bioFloww should both be placed on the floor. Again, they need to be diagonally opposite one another. (See diagram 1b.)
5. Attach the aquaFloww, the heatingFloww and the electroFloww with the cable ties supplied with the set (see diagrams 2, 3 and 4 respectively).
The cable ties should be wrapped around the brass, copper and stainless steel bands. (See below.)




diagram 1a



diagram 1b

a. aquaFloww (See diagram 2a).

Attach the aquaFloww to the water supply system:

- on the incoming water supply pipe
- between the water main and the water meter,
- by wrapping a cable tie around one of the two yellow brass bands and the water supply pipe.

Pull the cable tie tight so the aquaFloww is securely attached to the water supply pipe. Then do the same thing with the second cable tie.

Please note: if the incoming water supply pipe that leads to the water meter is shorter than the aquaFloww, wrap the second cable tie *around the stainless steel antenna rather than around the brass band.* (See diagram 2b.)



diagram 2a



diagram 2b

b. heatingFloww (See diagram 3).



Attach the heatingFloww to the central heating system:

- on any radiator,
- on a central heating pipe,
- under the heating switch,
- by wrapping a cable tie around one of the two stainless steel bands and the central heating pipe. Pull the cable tie tight so the heatingFloww is securely attached to the central heating pipe.



diagram 3

Then do the same thing with the second cable tie.



Please note:

If you have an underfloor or hot air heating system

Attach the heatingFloww to the vent pipe that extends from the central heating boiler.

If you have a gas fire

Attach the heatingFloww anywhere on the gas pipe.

c. electroFloww (See diagram 4).

Attach the electroFloww to the electrical system:

- on the incoming electric cable,
- between the electric grid and the electricity meter,
- by wrapping a cable tie around one of the two red copper bands and the electric cable.

Pull the cable tie tight so the electroFloww is securely attached to the electric cable.

Then do the same thing with the second cable tie.




diagram 4

Other instructions

Withdrawal symptoms

- During the first week some people experience so-called 'withdrawal symptoms', which can include mild headaches or nausea. We believe that this is because the body is no longer being exposed to the distorted frequencies that it has become accustomed to. If these symptoms persist for more than a week please contact the Floww Company or a therapist associated with the Floww Company.
- For the first two weeks make sure you drink enough (spring or mineral) water. Adults should drink at least 1.5 litres of water per day. Children over and up to the age of 12 should drink a litre and half a litre of water per day respectively.

When installing the set

- Place the geoFloww and the bioFloww in a dry place.
- Make sure that the geoFloww and the bioFloww are not exposed to wide fluctuations in temperature.

More advice on how to use the homeFloww set and details of the guarantee

More advice on how to use the homeFloww set, details of the guarantee, our brochure and instructions on how to use all of the Floww products can be found on and downloaded from our website www.geohealth.gr